



NOTES:

1. SEE EXPANSION TANK SYSTEM SCHEDULE FOR COMPONENT SIZES.
2. RELIEF VALVE FOR CHILLED WATER SYSTEM IS SHOWN. OMIT WHEN RELIEF VALVE IS SHOWN ON HEAT EXCHANGER DETAIL & SYSTEM IS USED ONLY FOR HOT WATER HEATING.
3. PROVIDE STRAINER IN AIR SEPARATOR WHEN INDICATED IN EXPANSION TANK SCHEDULE.
4. FOR HOT WATER SYSTEMS 50mm [2"] AND SMALLER AND CHILLED WATER SYSTEMS USE IN-LINE AIR PURGER IN LIEU OF AIR SEPARATOR.
5. SET PRESSURE REDUCING VALVE SO PRESSURE AT HIGHEST POINT IN SYSTEM HAS A MINIMUM OF 28kPa. [4 PSIG]

DESIGNER'S NOTE:
 VALVES SHALL BE INDICATED ON EITHER SIDE OF AIR SEPARATOR AS REQUIRED BY CLOSENESS OF VALVES SERVING ADJACENT EQUIPMENT. WHERE CHARGING OF TANK IS PROPOSED PROVIDE NECESSARY TAPPINGS. PROVIDE AND SHOW A LOW WATER ALARM ON CHARGED SYSTEMS TO INDICATE NO WATER IN TANK.

HORIZONTAL EXPANSION TANK - PIPING CONNECTIONS

NTS